

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
None	
8. Farm or Lease Name	
Natural	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Bagley Penn.	
12. County	
Lea	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Abandoned Oil Well	
2. Name of Operator	
Read & Stevens, Inc.	
3. Address of Operator	
P. O. Box 2126, Roswell, New Mexico 88201	
4. Location of Well	
UNIT LETTER B , 660 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 15 TOWNSHIP 12 South RANGE 33 East NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	
4256.4 GR.	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>
SUBSEQUENT REPORT OF:	
REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

On July 31, 1972

1. Set C. I. bridge plug @ 8700' Set 40' of cement on top of plug.

2. Ran tubing and loaded hole with mud, brine water and gel mixed 1 sx. of gel to 4 bbls. brine.

3. Cut and pulled 5 1/2" casing @ 4000'.

4. Set plugs as follows:  
70 sx. cement plug 4034'-3807'





5. Cut and pulled 8 5/8" casing @ 1476'.

6. Loaded hole with good mud.

7. Set cement plugs through 2" tubing as follows:  
70 sx. cement plug @ 1519'-1402'  
70 sx. cement plug @ 434'- 318'  
10 sx. cement plug @ 10'- 0'

8. Installed regulation marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED 	TITLE Agent	DATE April 25, 1974
APPROVED BY 	TITLE 	DATE 

CONDITIONS OF APPROVAL, IF ANY: