

COPIES RECEIVED		
DISTRIBUTION		
FE		
LE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
NM K4690	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
COQUINA OIL CORPORATION		Hanagan St.
3. Address of Operator		9. Well No.
200 Bldg. of the Southwest Midland, Texas 79701		1
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER K, 1650 FEET FROM THE South LINE AND 2310 FEET FROM		Lazy J - Penn
THE West LINE, SECTION 1 TOWNSHIP 13 RANGE 32 NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
4269 KB		Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

It is proposed to Plug and Abandon subject well in the following manner:

1. Fill hole w/ mud laden fluid.
2. Set CIBP @ 9700' and dump 35' cement on top of plug.
3. Cut off and pull 5 1/2" csg. @ Free point.
4. Set 100' cement plug at stub of 5 1/2" csg.
5. Set 100' cement plug at top of Glorietta @ 5460'.
6. Set 100' cement plug (50' in and 50' out) of 8 5/8" shoe @ 4030'.
7. Cut off and pull 8 5/8" csg. @ free point.
8. Set 100' cement plug at stub of 8 5/8" csg.
9. Set 100' cement plug (50' in and 50' out) of 13 3/8" shoe @ 360'.
10. Set 20' cement plug at surface and install DRY HOLE MARKER.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John T. Berry John T. Berry TITLE Engineer DATE 7-17-74

APPROVED BY Joe D. Berry TITLE Dist. I, Supv. DATE 7-17-74

CONDITIONS OF APPROVAL, IF ANY: