

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION

P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO. 30-025-22454
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No. —
7. Lease Name or Unit Agreement Name Anderson, E. B.
8. Well No. 2
9. Pool name or Wildcat SWD (Wolfcamp)
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3859' GR

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER SWD	
2. Name of Operator Kaiser-Francis Oil Company	
3. Address of Operator P. O. Box 21468, Tulsa, OK 74121-1468	
4. Well Location Unit Letter M : 990 Feet From The South Line and 990 Feet From The West Line Section 6 Township 13S Range 38E NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3859' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER: <input type="checkbox"/>	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is our intent to P&A the above well. Our proposed procedure is as follows:

1. Fish stuck tbg and Lok-set pkr @ 9426'.
2. Set CIBP @ 9530' w/35' cmt on top. Fill hole w/9.5# SW gel.
3. Perf 5½" csg @ 4530' w/4 holes.
4. Set cmt ret @ 4450' & pump 100 sxs cmt thru retainer & spot 20' cmt on top of retainer.
5. Set 25 sx cmt plug from 3400'-3200'.
6. Perf 5½" & 8 5/8" csg @ 422' w/4 holes.
7. Set cmt ret @ 350' & pump 100 sxs cmt thru retainer & spot 20' cmt on top of retainer.
8. Set 10 sx cmt plug from 30' to surface.
9. Cut off wellhead & install dryhole marker.

Estimated starting date: 5/15/96

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE C. Jan Valkenburg TITLE Technical Coordinator DATE 4/16/96  
TYPE OR PRINT NAME Charlotte Van Valkenburg 918-491-4314 TELEPHONE NO.

(This space for State Use)

APPROVED BY JOSEPH L. LIXION TITLE DISTRICT SUPERVISOR DATE APR 22 1996

CONDITIONS OF APPROVAL, IF ANY: