

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator <u>Tenneco Oil Company</u>		8. Farm or Lease Name <u>Maxwell</u>
3. Address of Operator <u>Box 1031 Midland, Texas 79701</u>		9. Well No. <u>2</u>
4. Location of Well UNIT LETTER <u>K</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>31</u> TOWNSHIP <u>14S</u> RANGE <u>35 E</u> NMPM.		10. Field and Pool, or Wildcat <u>North Morton</u>
15. Elevation (Show whether DF, RT, CR, etc.)		12. County <u>Lea</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

8-3-70 : (1) Set bridge plug @ 10300'± with 25x cmt on top.
(2) Cut & recover 5½" casing from 7000'±.
(3) Set 25 5x cmt plug over 5½" stub @ 7000'±.
(4) Set 25 5x cmt plug over 8⅞" cog shoe @ 4570'.
(5) Cut & recover 8⅞" Cog from 1000'±.
(6) Set 25 5x cmt plug over 8⅞" stub @ 1000'.
(7) Set 25 5x plug over 13⅞" cog shoe @ 411'.
(8) Set 25 5x plug @ surface inside 13⅞" cog.
(9) Erect dry hole marker.
(10) Clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED L. M. Williams TITLE Prod. Engr DATE 7-30-70

APPROVED BY [Signature] TITLE [Signature] DATE [Signature]

CONDITIONS OF APPROVAL, IF ANY:

55 x 55 (a) top (b) bottom

RECEIVED

JUL 8 1970

OIL CONSERVATION COMM.
HOUSTON, TEXAS