

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No
E-2490

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input type="checkbox"/> GAS <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Exxon Corporation	8. Farm or Lease Name N.M. "CH" State
3. Address of Operator P. O. Box 1600, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER 0 1980 FEET FROM THE East LINE AND 760 FEET FROM THE South LINE, SECTION 27 TOWNSHIP 12-S RANGE 34-E NMPM.	10. Field and Pool, or Wildcat West Ranger Lake Dev.
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Unseat Model R packer and circ. mud to 9000'. Pump 90 bbls. at a slow rate.
- Pull tubing and packer.
- Set C.I. bridge plug at 12,000' on wireline and dump 4 sx (40') of cmt. on top.
- Establish free point and cut 4-1/2" casing above it.
- Circ. mud to surface through 4-1/2" csg.
- Spot the following 100' Class H cement plug through the 4-1/2" casing. Pump all plugs down with mud:

SX	DEPTH	FOR
30	about 9,000'	Across 4-1/2" Casing Cut
30	7,735' - 7,835'	Abo
30	5,560' - 5,660'	Glorieta
30	4,210' - 4,310'	Across 8-5/8" Casing Shoe

- Pull 4-1/2" casing.
- Establish free point and cut 8-5/8" casing above it. Pull 8-5/8" casing.
- Run 2" tubing and spot Class "C" cement plugs as follows:

SX	DEPTH	FOR
50	about 2,500'	Across 8-5/8" Casing Cut
55	1,890' - 1,990'	Rustler
55	327' - 427'	Across 11-3/4" Casing Shoe
10	0 - 10'	Surface

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

10. Clean location and install dry hole marker.

SIGNED *Ed Beaudry* TITLE Unit Head DATE 4-18-73

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: