

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry Hole		7. Unit Agreement Name
2. Name of Operator Jack L. McClellan		8. Farm or Lease Name Dye
3. Address of Operator P.O. Box 848, Roswell N.M. 98201		9. Well No. 1
4. Location of Well UNIT LETTER P , 660' FEET FROM THE South LINE AND 660' FEET FROM THE East LINE, SECTION 28 TOWNSHIP 13S RANGE 34E NMPM.		10. Field and Pool, or Wildcat Cerca L. Wolfcam
15. Elevation (Show whether DF, RT, GR, etc.) 4145' G.L.		12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

On 4-3-70 Plugged and abandoned well as follows:

1. Set 15 Sack plug at 8915' in 4 1/2" Casing.
2. Set 25 Sack Plug at 4867', in and out of casing cut off.
3. Set 25 sack Plug at 4320' in base of 8 5/8" intermediate casing.
4. Set 25 sack plug at 1279' in and out of 8 5/8" casing cut off.
5. Set 25 Sack plug at 320' at Base of 12 3/4" Surface casing.
6. Set 10 Sack Plug at Surface in 12 3/4" Casing.
7. Installed Dry Hole Marker.

Drilling Mud was placed between plugs.
Casing Pullers, Inc. of Hobbs N.M. performed the above operations.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u><i>Dene Milford</i></u>	TITLE <u>Production Supt.</u>	DATE <u>4-22-70</u>
APPROVED BY <u><i>John W. Runyan</i></u>	TITLE <u>Geologist</u>	DATE <u>DEC 3 1970</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

APR 23 1970

OIL CONSERVATION COMM.
HOSEA, W. I.