

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name	
2. Name of Operator SIGNAL OIL & GAS COMPANY		8. Field or Lease Name LOWE LAND	
3. Address of Operator 125 Central Building, Midland, Texas 79701		9. Well No. 1	
4. Location of Well UNIT LETTER L 1980 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 35 TOWNSHIP 13-S RANGE 38-E N.M.P.M.		10. Field and Pool, or Wildcat SOUTH BRONCO - San Andres	
15. Elevation (Show whether DF, RT, GR, etc.) 3795 GL		12. County Lea	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set Cast Iron Bridge Plug @ 5300'.
2. Cut 4-1/2" casing @ approx. 4500'
3. Place 40 sk. cement plug at 5-1/2" csg. stub
4. Pull 4500' 4-1/2" casing.
5. Place 40 sk. cement plug at 4650' (shoe of 8-5/8" csg.)
6. Cut 8-5/8" csg. @ approx. 2500'.
7. Place 60 sk. cement plug @ 8-5/8" csg. stub.
8. Pull 2500' 8-5/8" casing.
9. Place 60 sk. cement plug at 380' (shoe of 13-3/8" csg.)
10. Place 10 sk. cement plug at surface, erect suitable marker.

We propose to commence this work 11-28-70.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D. J. Delany TITLE Division Production Engineer DATE November 25, 1970

APPROVED BY [Signature] TITLE SUPERVISOR DISTRICT DATE NOV 30 1970

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

NOV 3 1970

OIL CONSERVATION CO. INC.
HARRIS, N. J.