

COPIES RECEIVED	
TRIBUTION	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
NMK 4690	
7. Unit Agreement Name	
8. Farm or Lease Name	
Hanagan St.	
9. Well No.	
2	
10. Field and Pool, or Wildcat	
Lazy J. Penn	
12. County	
Lea	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator
COQUINA OIL CORPORATION
3. Address of Operator
200 Bldg. of the Southwest Midland, Texas 79701
4. Location of Well
UNIT LETTER <u>L</u> , 1980 FEET FROM THE <u>South</u> LINE AND <u>430</u> FEET FROM THE <u>West</u> LINE, SECTION <u>21</u> TOWNSHIP <u>13S</u> RANGE <u>33E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)
GL 4256 KB 4270

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to Plug and Abandon subject well in the following manner:

1. Fill hole w/ mud laden fluid.
2. Set CIBP @ 9700' and dump 35' cement on top of CIBP.
3. Cut off 5 1/2" csg at free point., Pull 5 1/2" csg.
4. Set 100' plug at stub of 5 1/2" csg.
5. Set 100' plug at top of Glorietta @ 5400'.
6. Set 100' plug (50' in and 50' out) at 8 5/8" csg shoe at 4199'.
7. Cut off and pull 8 5/8" csg at free point.
8. Set 100' plug at stub of 8 5/8" csg.
9. Set 100' plug (50' in and 50' out) at 13 3/8" csg. shoe @ 393'.
10. Set 20' plug at surface and install DRY HOLE MARKER.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <u>John T. Berry</u>	TITLE <u>Engineer</u>	DATE <u>7-17-74</u>
APPROVED BY _____	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		