Form 9-331 (May 1963)

16.

D STATES SUBMIT IN TRIPLICATE* Of THE INTERIOR (Other instructions reverse side) UNITED STATES DEPARTMEN

WATER SHUT-OFF

FRACTURE TREATMENT

Form approved. Budget Bureau No. 42-R1424. 5. LEASE DESIGNATION AND SERIAL NO.

LO 060581

10. FIELD AND POOL, OR WILDCAT

SUBSEQUENT REPORT OF:

North Bagley Penn (Lower 11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

ALTERING CASING

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

GEOLOGICAL SURVEY

SUNDRY NOTICES	AND	REPORTS	ON	WELLS
----------------	-----	----------------	----	-------

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.

Use "APPLICATION FOR PERMIT—" for such proposals.)

7. UNIT AGREEMENT NAME None MELT X GAS WELL S. FARM OR LEASE NAME NAME OF OPERATOR Federal 10 Anderson Gil and Gas Company, Inc. 9. WELL NO. ADDRESS OF OPERATOR

250 Mid-America Puilding, Midland, Jexas 79701 Cooking on well (Report location clearly and in accordance with any State requirements.)

See also space 17 below.)

At surface

PULL OR ALTER CASING

MULTIPLE COMPLETE

1980' FNL & 1830' FWL Sec. 10, T-12-S, R-33-E

NOTICE OF INTENTION TO:

Sec.10, T-12S, R-33L 12. COUNTY OR PARISH 13. STATE 15. ELEVATIONS (Show whether DF, RT, GR, etc.) 14. PERMIT NO. New Mexic. 4247 GL Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

SHOOTING OR ACIDIZING X ABANDONMENT* ABANDONS SHOOT OR ACIDIZE REPAIR WELL (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OF COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* 11-14-72 Move in completion unit and rig up Welex perforators. Run Gamma ray correlation

log from PETD (9641') to 3000'. Perforate 5 1/2" casing w/10 -0.45" holes as follows:

9356: 96

TEST WATER SHUT-OFF

FRACTURE TREAT

(Other)

9428, 31, 38, 42, 44, 46, 62, 63, 87, 91, 92, 96, 98, 99

9537, 54.

Acidize Lower Penn, Zone with 3300 gallons DS-30 15% acid. Shut down for night.

Swab lower Penn Zone with a good show of oil and gas.

Pulled tubing and packer prep to install pump.

Picked up Baker 5 1/2" packer and Armco 2 1/2" bottom hole assembly and ran 11-17-72 to 9243 on 2 1/2" tubing. Set packer @ 9218' and shut down for the night.

11-18-72 Repair surface pump and start well circulating.

11-19-72 Install Armoo free style 2 1/2" VFR Subsurface pump and start well pumping.

11-20-72 Well pumping 140 BO + 96 BW/D with 1600# surface pressure @ 88spm.

18. I hereby certify that the foregoing as true and correct		
SIGNED Allance Alla T	TTLE Engineer	DATE 11-22-72
(This space for Federal or State office use)		

APPROVED BY CONDITIONS OF APPROVAL, IF ANY:

ACCEPTED FOR TRECORD

NOV 24 1972

*See Instructions on Reverse Side

U. S. GEOLUGICAL SURVEY HOBBS, NEW MEXICO