M /	
<u> </u>	
NO. OF COPIES RECEIVED	Form C-103
DISTRIBUTION	Supersedes Old
SANTA FE NEW MEXICO OIL CONSERVATION COL	C-102 and C-103 MMISSION Effective 1-1-65
FILE	211301146 1-1-03
	oa. Indicate Type of Lease
U.S.G.S.	
LAND OFFICE	
OPERATOR). State Otl & Gas Lease No.
	L-6798
SUNDRY NOTICES AND DEPORTS ON WELLS	
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFEREN USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	AT RESERVOIR.
1.	
OIL GAS C	7. Unit Agreement Name
WELL X WELL OTHER-	
2. Name of Operator	3, Farm or Lease Name
Read & Stevens, Inc.	South King
3. Address of Operator	3. Well No.
	·
P. O. Box 2126, Roswell, New Mexico 88201	
4. Location of Well	0. Field and Pool, or Wildcat
UNIT LETTER P , 1200 FEET FROM THE SOUTH LINE AND	660 South King
UNIT LETTER LINE AND	FEET FROM
THE East LINE, SECTION 2 TOWNSHIP 14-S RANGE 3	7-E NMPN: ()
15. Elevation (Show whether DF, RT, GR, etc.) 2. County
(1)	Lea
10	
Check Appropriate Box To Indicate Nature of Notice	ce, Report or Other Data
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK PLUG AND ABANDON X REMEDIAL WORK	
PERFORM REMEDIAL WORK PLUG AND ABANDON A REMEDIAL WORK	ALTERING CASING
TEMPORARILY ABANDON COMMENCE DRILL	ING OPNS. PLUG AND ABANDONMENT
PULL OR ALTER CASING CASING TEST AND	CEMENT JOB
OTHER	
OTHER	
17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pert	inent dates, including estimated date of starting any proposed
work) SEE RULE 1103.	, and a second configuration of the second configuration o
1. Received permission to P and A from Mr. Joe Ramey vi	a telephone [1:00 A.M. 12-28-72.
λ Hole fill of dood mid. $12-29-12$	
2. Hole full of good mud. 12-29-72	
3. Set 35 Sks cement plug 12,570' to 12,470'	
3. Set 35 Sks cement plug 12,570' to 12,470' " " 11,550' to 11,450'	
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " 11,550' to 11,450' " " " 9,480' to 9,380'	
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " 11,550' to 11,450' " " " 9,480' to 9,380'	
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " 11,550' to 11,450' " " " 9,480' to 9,380' " " " 8,010' to 7,910'	
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " " 11,550' to 11,450' " " " " 9,480' to 9,380' " " " " 8,010' to 7,910' " " " 6,150' to 6,050'	
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " " 11,550' to 11,450' " " " " 9,480' to 9,380' " " " " 8,010' to 7,910' " " " 6,150' to 6,050' " " " 4,740' to 4,640'	
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " " 11,550' to 11,450' " " " " 9,480' to 9,380' " " " " 8,010' to 7,910' " " " 6,150' to 6,050'	
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " " 11,550' to 11,450' " " " 9,480' to 9,380' " " " 8,010' to 7,910' " " " " 6,150' to 6,050' " " " " 4,740' to 4,640' Cut and removed 8 5/8" casing.	5/8" stub.
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " " 11,550' to 11,450' " " " " 9,480' to 9,380' " " " " 8,010' to 7,910' " " " " 6,150' to 6,050' " " " " " 4,740' to 4,640' Cut and removed 8 5/8" casing. Set 50 Sks Cement plug 50' in and 50' out of 8	5/8" stub.
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " " 9,480' to 9,380' " " " " 8,010' to 7,910' " " " " 6,150' to 6,050' " " " " 4,740' to 4,640' Cut and removed 8 5/8" casing. Set 50 Sks Cement plug 50' in and 50' out of 8 Set 65 " " " 420' to 320'	5/8" stub.
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " " 11,550' to 11,450' " " " " 9,480' to 9,380' " " " " 8,010' to 7,910' " " " " 6,150' to 6,050' " " " " " 4,740' to 4,640' Cut and removed 8 5/8" casing. Set 50 Sks Cement plug 50' in and 50' out of 8	5/8" stub.
3. Set 35 Sks cement plug	5/8" stub.
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " " 9,480' to 9,380' " " " " 8,010' to 7,910' " " " " 6,150' to 6,050' " " " " 4,740' to 4,640' Cut and removed 8 5/8" casing. Set 50 Sks Cement plug 50' in and 50' out of 8 Set 65 " " " 420' to 320'	5/8" stub.
3. Set 35 Sks cement plug	5/8" stub.
3. Set 35 Sks cement plug	5/8" stub.
3. Set 35 Sks cement plug	5/8" stub.
3. Set 35 Sks cement plug	5/8" stub.
3. Set 35 Sks cement plug	5/8" stub.
3. Set 35 Sks cement plug 12,570' to 12,470' """""""""" 9,480' to 9,380' """""""" 8,010' to 7,910' """""""" 6,150' to 6,050' """"""" 4,740' to 4,640' Cut and removed 8 5/8" casing. Set 50 Sks Cement plug 50' in and 50' out of 8 Set 65 """ 420' to 320' Set 10 """" 10' to 0' 4. Install regulation marker and clean location.	
3. Set 35 Sks cement plug	
3. Set 35 Sks cement plug 12,570' to 12,470' """""""""" 9,480' to 9,380' """""""" 8,010' to 7,910' """""""" 6,150' to 6,050' """"""" 4,740' to 4,640' Cut and removed 8 5/8" casing. Set 50 Sks Cement plug 50' in and 50' out of 8 Set 65 """ 420' to 320' Set 10 """" 10' to 0' 4. Install regulation marker and clean location.	
3. Set 35 Sks cement plug """""""""""""1,550' to 11,450' """""""""" 9,480' to 9,380' """"""""" 6,150' to 6,050' """"""""" 4,740' to 4,640' Cut and removed 8 5/8" casing. Set 50 Sks Cememt plug Set 65 """" 420' to 320' Set 10 """" 10' to 0' 4. Install regulation marker and clean location.	nd belief.
3. Set 35 Sks cement plug 12,570' to 12,470' """""""""" 9,480' to 9,380' """""""" 8,010' to 7,910' """""""" 6,150' to 6,050' """"""" 4,740' to 4,640' Cut and removed 8 5/8" casing. Set 50 Sks Cement plug 50' in and 50' out of 8 Set 65 """ 420' to 320' Set 10 """" 10' to 0' 4. Install regulation marker and clean location.	
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " " " 9,480' to 9,380' " " " " " 8,010' to 7,910' " " " " 6,150' to 6,050' " " " 4,740' to 4,640' Cut and removed 8 5/8" casing. Set 50 Sks Cement plug 50' in and 50' out of 8 Set 65 " " 420' to 320' Set 10 " " 10' to 0' 4. Install regulation marker and clean location.	nd belief.
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " " " 9,480' to 9,380' " " " " 8,010' to 7,910' " " " " 6,150' to 6,050' " " " 4,740' to 4,640' Cut and removed 8 5/8" casing. Set 50 Sks Cement plug 50' in and 50' out of 8 Set 65 " " 420' to 320' Set 10 " " 10' to 0' 4. Install regulation marker and clean location.	nd belief.
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " " " 11,550' to 11,450' " " " " 9,480' to 9,380' " " " 8,010' to 7,910' " " " 6,150' to 6,050' " " " 4,740' to 4,640' Cut and removed 8 5/8" casing. Set 50 Sks Cement plug 50' in and 50' out of 8 Set 65 " " 420' to 320' Set 10 " " 10' to 0' 4. Install regulation marker and clean location.	nd belief.
3. Set 35 Sks cement plug 12,570' to 12,470' " " " " " " 11,550' to 11,450' " " " " 9,480' to 9,380' " " " 8,010' to 7,910' " " " 6,150' to 6,050' " " " 4,740' to 4,640' Cut and removed 8 5/8" casing. Set 50 Sks Cement plug 50' in and 50' out of 8 Set 65 " " 420' to 320' Set 10 " " 10' to 0' 4. Install regulation marker and clean location.	DATE 1-8-73