

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-24294
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	LG-1333
7. Lease Name or Unit Agreement Name	
Midwest XV State	
8. Well No.	1
9. Pool name or Wildcat	Undes. Saunders Permo Upper Penn

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator YATES PETROLEUM CORPORATION
3. Address of Operator 105 South 4th St., Artesia, NM 88210	4. Well Location Unit Letter <u>B</u> : <u>660</u> Feet From The <u>North</u> Line and <u>1980</u> Feet From The <u>East</u> Line Section <u>19</u> Township <u>14S</u> Range <u>33E</u> NMPM Lea County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4262' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
<b>NOTICE OF INTENTION TO:</b>	<b>SUBSEQUENT REPORT OF:</b>
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well as follows:

1. Set CIBP at 9550'. Cap with 35' of cement.
2. Freepoint 5-1/2" casing and cut 50' above freepoint. Pull 5-1/2" casing.
3. GIH w/tubing and load hole with salt gel mud.
4. Spot 35 sack plug 50' inside 5-1/2" casing stub. Tag this plug at least 50' above stub. Will respot with 35 sacks if necessary.
5. Pull up and spot 35 sacks across top of Abo at 7720'.
6. Pull up and spot 35 sacks across top of Glorieta at 5570'.
7. Pull up at spot 50 sacks at 4225'. Tag this plug at 4100' or higher. If no tag, will respot another 35 sack plug.
8. Spot 35 sack plug at 465'.
9. Perforate 8-5/8" casing at 300'. Pump down casing & circulate out 8-5/8" & 13-3/8" annulus. Pump 100 sacks. Leave 100' of cement inside casing. CONTINUED

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Production Clerk DATE June 17, 1993  
TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505/748-1471

(This space for State Use) ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

JUN 22 1993

**RECEIVED**

JUN 21 1993

W.D. HOBBS  
OFFICE