

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR THE ABANDONMENT OF A WELL OR FOR PLUGGING A WELL TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT TO ABANDON (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Dry Hole</b>		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator <b>TEXACO Inc.</b>		5. State Oil & Gas Lease No. <b>K-6678-1</b>
3. Address of Operator <b>P. O. Box 728, Hobbs, New Mexico 88240</b>		7. Unit Agreement Name <b>-</b>
4. Location of Well UNIT LETTER <b>B</b> <b>810</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM THE <b>East</b> LINE, SECTION <b>19</b> TOWNSHIP <b>12-S</b> RANGE <b>34-E</b> N.M.P.M.		8. Form of Lease Name <b>N.M. 'DP' State</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4207' (DF)</b>		9. Well No. <b>1</b>
		10. Field and Pool, or Wildcat <b>Undesignated</b>
		12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP @ 9650'. Spot 35' plug (4 sx.) on top of CIBP. - Plug #1 9650'-9615'.
2. Spot 110' Cement plug (15 sx.) #2 from 4100-3990'.
3. Cut 5 1/2" casing @ 3479'. Pulled 121 Jts (3479') 5 1/2" 17# Csg.
4. Spot 125' Cement plug (35 sx.) #3 from 3525'-3400'.
5. Spot 100' Cement plug (35 sx.) #4 from 2800'-2700'.
6. Spot 100' Cement plug (35 sx.) #5 from 1800'-1700'.
7. Cut 8 5/8" casing @ 1205'. Pulled 35 jts (1205') 8 5/8" csg.
8. Spot 100' casing @ (100 sx.) #6 from 1250'-1150'.
9. Spot 100' casing @ (100 sx.) #7 from 405'-305'.
10. Spot 10' casing @ (10 sx.) #8 from 10'-Surface.
11. Install Dry Hole Marker & Clean Location.
12. Well P & A, 4-24-76.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *[Signature]* TITLE Asst. Dist. Supt. DATE 4-26-76  
APPROVED BY *[Signature]* TITLE OIL & GAS INSPECTOR DATE JUL 8 1976  
CONDITIONS OF APPROVAL, IF ANY: