

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name ---
8. Farm or Lease Name State '30'
9. Well No. #2
10. Field and Pool, or Wildcat Baum (Upper Penn)
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.

1. ☒ OIL ☐ GAS WELL ☐ OTHER-

2. Name of Operator
R. L. Burns Corp.

3. Address of Operator
5110 First International Building, Dallas, Texas 75270

4. Location of Well
UNIT LETTER B, 660 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 30 TOWNSHIP 13S RANGE 33E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
4282' gr.

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of completion of any proposed work) SEE RULE 1103.

To plug and abandon well as follows:

- Load hole with mud, set cement retainer on tubing at 9750', and set 35' cement plug above retainer.
- Find free point in 5½" casing, cut and pull casing, with tubing, set following cement plugs:
 - 100' plug in and out of stub of 5½" casing.
 - 100' plug at top of Abo if not behind pipe.
 - 100' plug at top of Glorietta if not behind pipe.
 - 100' plug in and out of shoe of 8-5/8" casing.
- Find free point in 8-5/8" casing, cut and pull casing, with tubing, set following cement plugs:
 - 100' plug in and out of stub of 8-5/8" casing.
 - 100' plug above top of Salt if not behind casing.
 - 100' plug in and out of shoe of surface casing.
- Set 10 sack plug at surface with marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief

SIGNED David M. Reavis TITLE Production Engineer DATE Feb. 24, 1978
David M. Reavis R.L. Burns Oil & Gas Corp.
Oil & Gas Corp. Agent for R.L. Burns Corp.

APPROVED BY _____ TITLE _____ DATE MAR 1 1978

CONDITIONS OF APPROVAL, IF ANY: THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

RECEIVED

FEB 28 1978

OIL CONSERVATION COMM.
HOBBS, N. M.