

COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
LG 1481	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry Hole		7. Unit Agreement Name
2. Name of Operator Oil Development Company of Texas		8. Farm or Lease Name State 9
3. Address of Operator P. O. Box 12058 Amarillo, Texas 79101		9. Well No. 1
4. Location of Well UNIT LETTER K 2080 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 9 TOWNSHIP 13S RANGE 32E NMPM.		10. Field and Pool, or Wildcat Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 4346.5 KB		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:	
REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to plug and abandon the subject well as follows:

1. Load hole with mud laden fluid
2. Pull tubing
3. Set Bridge Plug at 10,150' and cap w/35' of cement
4. Shoot off and pull 5-1/2" casing
5. Spot cement plugs as follows:
 - a. 100' plug 50' below casing cut off
 - b. 100' plug from 8445-8545' (Wolfcamp) if above casing cut off.
 - c. 100' plug from 7235-7335' (Abo) if above casing cut off.
 - d. 100' plug from 5050-5150' (Glorietta) if above casing cut off
 - e. 100' plug from 3758-3858' (8-5/8" shoe)
 - f. 100' plug from 1468-1568' (salt formation)
6. Cut off casing below ground level, set 10 sx plug at surface and install Marker.

The above procedure was approved by phone with the NMOCC.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John Runyan TITLE Petroleum Engineer DATE 9/27/77

APPROVED BY John Runyan TITLE Geologist DATE OCT 3 1977

CONDITIONS OF APPROVAL, IF ANY:

Expires 4/3/78