

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

U.S. CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease  
State ☐ Fee ☒  
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT - I" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Kimbark Oil & Gas Company	8. Farm or Lease Name M. F. Walker
3. Address of Operator Two First City Center, Suite 665, Midland, Texas 79701	9. Well No. #1
4. Location of Well UNIT LETTER 0 1980 FEET FROM THE East LINE AND 660 FEET FROM THE South LINE, SECTION 27 TOWNSHIP 12-S RANGE 37-E N.M.P.M.	10. Field and Pool, or Wildcat S.W. Gladiola Devonian
15. Elevation (Show whether DF, RT, GR, etc.) 3891.7	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	



17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work; SEE RULE 1103.)

1. Pull tubing.
2. Set CIBP on Wireline @ 12200'
3. Dump 2 sx cement on top of CIBP.
4. Cut off and recover 5-1/2" csg as deep as possible, Approx 5400'.
5. Set 50 sx cement plug in and out of csg stub.
6. Set 50 sx cement plug in and out of base of intermediate csg, approx 4497'.
7. Set 40 sx cement plug @ 1500'.
8. Set 10 sx cement plug in top of 8-5/8" csg.
9. Cut off 8-5/8" and 13-3/8" below surface flange - weld plate over 13-3/8" and 8-5/8" - 3' below ground level. Install dry hole marker. Clean up and level location.

\*\*\*100' plug @ top of Abo--7900'  
Tag 5 1/2" stub plug  
Load hole with 10# salt gel after CIBP is set

OPERATIONS FOR THE C-103  
IS APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED 	TITLE Dist. Superintendent	DATE 5-7-85
APPROVED BY 	TITLE OIL & GAS INSPECTOR	DATE MAY 8 1985
CONDITIONS OF APPROVAL, IF ANY: ***SEE ABOVE		