

NO. OF COPIES RECEIVED			
DISTRIBUTION			
SANTA FE			
FILE			
U.S.G.S			
LAND OFFICE			
OPERATOR			

5a. Indicate Type of Lease  
State ☒ Fee ☐

---

5. State Oil & Gas Lease No.

V-720

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT-" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL	GAS		
WELL <input type="checkbox"/>	WELL <input type="checkbox"/>	OTHER	Dry hole

7. Unit Agreement Name
------------------------

2. Name of Operator  
Read & Stevens, Inc.

8. Farm or Lease Name  
Tres Papalotes

3. Address of Operator  
P.O. Box 1518, Roswell, NM 88201

9. Well No. 1

4. Location of Well

UNIT LETTER N . 1980 FEET FROM THE West LINE AND 660 FEET FROM  
THE South LINE. SECTION 28 TOWNSHIP 14S RANGE 34E NMPM

10. Field and Pool, or Wildcat
Tres Papalotes
XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX

XXXXXXXXXXXXXXXXXXXXXXXXXXXX	5. Elevation(Show whether DF,RT,GR,etc.)
XXXXXXXXXXXXXXXXXXXXXXXXXXXX	4123' GL

12. County	XXXXXXXXXXXXXXXXXXXX
Lea	XXXXXXXXXXXXXXXXXXXX

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>	PLUG AND ABANDON	<input checked="" type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>	CHANGE PLANS	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>		
OTHER	<input type="checkbox"/>		

SUBSEQUENT REPORT OF:

REMEDIAL WORK		ALTERING CASING	
COMMENCE DRILLING OPNS.		PLUG AND ABANDONMENT	
CASING TEST AND CEMENT JOB			
OTHER			

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Set CIBP @ 10,380', spot 35' cement on top of plug.
- 2) Circulate hole w/salt gel mud.
- 3) Spot 25sx cement plug 9600'-9700'.
- 4) Cut 5 1/2" casing @ +6000', spot 35sx cmt plug 1/2 in and 1/2 out of csg stub 5950'-6050'.
- 5) Spot 35sx plug across 8 5/8" csg shoe, 4500'-4600'.
- 6) Spot 35sx plug 1550'-1650'.
- 7) Spot 10sx surface plug 0-30', install dry hole marker.
- 8) Clean location, cut anchors and prep for final inspection.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature]

TITLE Drilling and Production Manager

DATE 8-21-84

APPROVED BY Eddie W. Seay  
Oil & Gas Inspector  
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE \_\_\_\_\_

AUG 23 1984