

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
2. Name of Operator Monument Energy Corporation		5. State Oil & Gas Lease No.
3. Address of Operator Box 1476, Lovington, New Mexico 88260		7. Unit Agreement Name
4. Location of Well UNIT LETTER <u>M</u> <u>660</u> FEET FROM THE <u>south</u> LINE AND <u>660</u> FEET FROM THE <u>west</u> LINE, SECTION <u>25</u> TOWNSHIP <u>7S</u> RANGE <u>32E</u> NMPM.		8. Farm or Lease Name Atlantic Tucker
15. Elevation (Show whether DF, RT, GR, etc.) 4438.3 GR		9. Well No. 2
		10. Field and Pool, or Wildcat Chaveroo San Andres
		12. County Roosevelt

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Rigged up and pulled rods and tubing. Set CIBp @ 4000' Dumped 5 sacks cement on top of plug. Circulated hole with 25 sacks salt gel and 10# brine water. Shot casing @ 1202' and recovered same. Went in hole with tubing and set 35 sack plug @ casing stub. Pulled tubing to 350' and set 35 sack plug at bottom of surface casing. Set P & A marker with 10 sacks cement at surface.

Used Permian Basin Casing Pullers to plug well.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C. H. Deely TITLE Production Foreman DATE 3/1/77  
 APPROVED BY John W. Runyan TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
 CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

10/11/57  
CL. OFF. OF THE  
FBI, WASH. D. C.