

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
L-4401	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Enserch Exploration, Inc.		8. Farm or Lease Name Amoco State
3. Address of Operator P.O. Box 4815 Midland, Texas		9. Well No. 1
4. Location of Well UNIT LETTER <u>L</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>16</u> TOWNSHIP <u>4S</u> RANGE <u>33E</u> NMPM.		10. Field and Pool, or Wildcat North Peterson (Penn)
15. Elevation (Show whether DF, RT, GR, etc.) 4387.7 GR		12. County Roosevelt

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plans are to plug and abandon this well as follows:

Verbal approval (May 22, 1983) was given for the following procedure:

Set retainer at 6650', squeeze casing with 25 sacks Class H cement with 3/10 of 1% Halad 9 and 19 sacks Class H neat.

Dump 6' cement plug on top of retainer.

Lay 40 sack Class H cement plug from 4050'-4150'.

Cut off 5-1/2" casing at 3000'.

Lay 40 sack Class H cement plug from 2950'-3050'. RIH and tag plug.

Lay 100 sack Class H cement plug from 1900'-2150'. RIH and tag plug.

Lay 40 sack Class H cement plug from 1550'-1650'. RIH and tag plug.

Lay 10 sack Class H cement plug at surface.

Cut off 9-5/8" casinghead.

Weld steel plate on 9-5/8" casing.

Install dry hole marker.

\* Mudladen fluid between all plugs.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Nancy Dale Nancy Dale TITLE Petroleum Engineer DATE May 25, 1983

APPROVED BY ORIGINAL SIGNED BY JERRY SEXTON TITLE DISTRICT 1 SUPERVISOR DATE MAY 27 1983

CONDITIONS OF APPROVAL, IF ANY: