

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee   
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- 2. Name of Operator <b>Enserch Exploration, Inc.</b> 3. Address of Operator <b>P.O. Box 4815 Midland, Texas 79704</b> 4. Location of Well UNIT LETTER <b>D</b> , <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>5</b> TOWNSHIP <b>5</b> RANGE <b>33E</b> NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) <b>4471.3 GR</b>	7. Unit Agreement Name 8. Farm or Lease Name <b>Terry</b> 9. Well No. <b>1</b> 10. Field and Pool, or Wildcat <b>Peterson-Mississippi</b> 12. County <b>Roosevelt</b>
--	---

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK  PLUG AND ABANDON   
TEMPORARILY ABANDON  CHANGE PLANS   
PULL OR ALTER CASING  OTHER

SUBSEQUENT REPORT OF:

REMEDIAL WORK  ALTERING CASING   
COMMENCE DRILLING OPNS.  PLUG AND ABANDONMENT   
CASING TEST AND CEMENT JOB  OTHER

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plans are to plug and abandon this well as follows:

A verbal approval (May 16, 1983) was given for the following procedure:

Set retainer at 6080', squeeze casing with 25 sacks Class H cement with 3/10% Halad 9 and 25 sacks Class H neat.

Dump 5 cement plug on top of retainer.

Lay 40 sack Class H cement plug from 4150'-4050'.\*

Cut of 5-1/2" casing @ 3000'

Lay 40 sack Class H cement plug from 2950'-3050'. RIH and tag plug.

Lay 100 sack Class H cement plug from 1800'-2050'. RIH and tag plug.

Lay 40 sack Class H cement plug from 1550'-1650'. RIH and tag plug.

Lay 10 sack Class H cement plug at surface.

Cut of 9-5/8" casinghead

Weld steel plate on 9-5/8" casing.

Install dry hole marker.

\*Mudladen fluid between all plugs

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Nancy Dale Nancy Dale TITLE Petroleum Engineer DATE May 20, 1983

ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

MAY 25 1983

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED  
MAY 24 1983  
O.C.D.  
HOBBS OFFICE