

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-041-20637
5. Indicate Type of Lease Federal <input type="checkbox"/> STATE <input type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. Federal NM 37611
7. Lease Name or Unit Agreement Name Scott Federal #2 SWD
8. Well No. 2 SWD
9. Pool name or Wildcat SWD - Montoya

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER SWD Well <input type="checkbox"/>	
2. Name of Operator EP Operating Limited Partnership	
3. Address of Operator 6 Desta Drive, Suite 5250, Midland, TX 79705-5510	
4. Well Location Unit Letter <u>B</u> : <u>660</u> Feet From The <u>North</u> Line and <u>1980</u> Feet From The <u>East</u> Line Section <u>20</u> Township <u>4S</u> Range <u>33E</u> NMPM <u>Roosevelt</u> County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) <u>4410' GR</u>	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER: <input type="checkbox"/>	SUBSEQUENT REPORT OF: REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug well as follows:
Set CIBP @ 8650'. Dump 3 sacks cement on plug. Circulate hole with mud laden fluid. Cut 5-1/2" casing at approximately 4000' and pull out of hole. Pump 40 sack cement plug from 3950' in 8-3/4" open hole to 4050' inside 5-1/2" casing stub. Tag plug at 3950'. Pump 60 sack cement plug from 1943' to 2043' across 9-5/8" casing shoe. Tag plug at 1943'. Pump 50 sack cement plug from 900' to 1000' inside 9-5/8" casing. Lay 10 sack cement surface plug. Cut off casing 3' below ground level. Install plate and dry hole marker. Work is tentatively scheduled to start June 1, 1994.

OK
3/2/2009
BET

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE S. D. Reed TITLE Production Superintendent DATE 05-05-94
TYPE OR PRINT NAME S. D. Reed (915) 682-9756 TELEPHONE NO.

(This space for State Use)

FOR RECORD ONLY

APPROVED BY _____ TITLE DISTRICT I SUPERVISOR DATE _____

CONDITIONS OF APPROVAL, IF ANY:

ORIGINAL SIGNED BY JERRY SEXTON
MAY 11 1994

RECEIVED

MAY 1 1964

COMMUNICATIONS
OFFICE