

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State Fee
5. State Oil & Gas Lease No.
OG 5937

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Union Oil Company of California	8. Farm or Lease Name State "C"
3. Address of Operator P. O. Box 671, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER M 330 FEET FROM THE South LINE AND 990 FEET FROM THE West LINE, SECTION 28 TOWNSHIP 15-S RANGE 32-E NMPM.	10. Field and Pool, or Wildcat No. And. Ranch Wolf.
15. Elevation (Show whether DF, RT, GR, etc.) 4335 DF	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Subject to approval, we plan to plug and abandon the above well using the following procedure:

Mix and spot 20 sacks of cement from 10,033' to 9,756'. Spot plug with mud and pull out with tubing. Lead 4-1/2" casing with mud and shoot off casing at free point. Pull out with casing and spot 40 sack cement plug in and out of 4-1/2" casing stub. Spot 50 sack cement plug across 8-5/8" casing shoe and shoot off 8-5/8" casing at free point. Pull out with 8-5/8" casing and spot 90 sack cement plug in and out of 8-5/8" casing stub. Spot 90 sack cement plug across 11-3/4" casing shoe and 10 sack cement plug from 20' to surface. Weld on vented steel plate and install dry hole marker.

*25 lbs @ top (located in 4 1/2" casing)
is to be cemented*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED: R.G. Ladd, Jr. TITLE: District Drilling Supt. DATE: January 11, 1968
APPROVED BY: [Signature] TITLE: _____ DATE: _____
CONDITIONS OF APPROVAL, IF ANY: