

COPIES RECEIVED		
TRIBUTION		
FE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
E-3510	
7. Unit Agreement Name	
8. Farm or Lease Name	
Lea CR State (NCT-A)	
9. Well No.	
4	
10. Field and Pool, or Wildcat	
Anderson Ranch Morrow	
12. County	
Lea	

SUNDY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -1" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator
	Gulf Oil Corporation
3. Address of Operator	
	Box 670, Hobbs, New Mexico 88240
4. Location of Well	
UNIT LETTER <u>K</u> , <u>3640</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>2</u> TOWNSHIP <u>16-S</u> RANGE <u>32-E</u> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	
	4282' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Plug and abandon</u> <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
		OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

13,500' TD.

Pull producing equipment. Set CI BP at 11,999', on top of Baker Model D packer at 12,000' and cap BP with 2 sacks of cement. Test BP with 600#, 30 minutes. Cut and recover 7" casing at free point. Cut and recover 9-5/8" casing at free point. Spot 100' cement plug in and out of 7" casing stub, 100' cement plug from 6850' to 6950', across Tubbs, 100' cement plug from 5650' to 5750', across Glorieta, 100' cement plug from 4150' to 4250', across 9-5/8" shoe at 4200', 100' cement plug in and out of 9-5/8" casing stub and 50' cement plug from 50' to surface. Install dry hole marker and clean location.

THIS DOCUMENT IS THE PROPERTY OF THE NEW MEXICO OIL CONSERVATION COMMISSION. IT IS LOANED TO YOU FOR YOUR INFORMATION AND USE ONLY. IT IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED K. J. Benzale TITLE Area Engineer DATE February 26, 1974

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: