

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B 3610
7. Unit Agreement Name
8. Farm or Lease Name Phillips Lexco State
9. Well No. Phillips 1
10. Field and Pool, or Wildcat Maljama r
12. County Lea

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>	
1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER: Injection well	7. Unit Agreement Name
2. Name of Operator Ryder Scott Management Company	8. Farm or Lease Name Phillips Lexco State
3. Address of Operator 922 - 8th Street, Wichita Falls, Texas 76301	9. Well No. Phillips 1
4. Location of Well UNIT LETTER N 1980 FEET FROM THE West LINE AND 660 FEET FROM THE South LINE, SECTION 2 TOWNSHIP 17 RANGE 32 NMPM.	10. Field and Pool, or Wildcat Maljama r
15. Elevation (Show whether DF, RT, GR, etc.) no record	12. County Lea

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Work to start on approval (approximately 3-18-68)

We will pull all retrievable tubing, install cast iron bridge plug above top perforations, fill casing and hole with mud-laden fluid, pull casing & install 10 sack cement plug in surface pipe. Erect marker & clean up surface.

1. Cap bridge plug w cement
2. 25 sxs @ stub
3. 25 sxs @ top of soil, if exposed
4. 25 sxs across surface casing sho
5. 10 sxs @ surface

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Mac Howard TITLE Asst. Prod. Supt. DATE March 11, 1968

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

Joe Kennedy