

UNITED STATES DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPlicate
(Other instructions on
reverse side)

Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER Water Injector		5. LEASE DESIGNATION AND SERIAL NO. NM 0315712	
2. NAME OF OPERATOR Chevron U.S.A. Inc.		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR P. O. Box 670, Hobbs, NM 88240		7. UNIT AGREEMENT NAME Maljamar Grayburg Unit	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface Unit N 660' FSL & 2310' FWL		8. FARM OR LEASE NAME	
14. PERMIT NO.		9. WELL NO. 26	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4101' GL		10. FIELD AND POOL, OR WILDCAT Maljamar Grayburg San Andr	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec 4 T17S R32E	
		12. COUNTY OR PARISH Lea	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒
☐
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐
☐
☐

REPAIRING WELL

☐
☐
☐
☐
☐

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Received verbal approval from Bob Pitsche, with the BLM in Carlsbad, to P&A this well on 10-31-1985 as follows:

- 1) Set CIBP @ 3800'± and cap with 35' of cement to seal off perforations from 3844' - 4000'.
- 2) Set 100' cement plug from 3150' - 3250' to cover top of Queen.
- 3) Set 100' cement plug from 2150' - 2250' to cover base of salt.
- 4) Perforate @ 1000'. Set cement retainer @ 950' and cement from 900' - 1000' behind casing, then cap with 50' of cement.
- 5) Set 100' cement plug 244' - 344' to cover surface casing shoe.
- 6) Perforate @ 100' and cement from 100' - 0' inside and outside 5½" casing.
- 7) Set dry hole marker with appropriate markings.

18. I hereby certify that the foregoing is true and correct.

SIGNED

P. S. Bullock Jr.

TITLE

Division Drilling Manager

DATE

3-25-1986

(This space for Federal or State office use)

Orig: Sgd, Charles S. [unclear]

APPROVED BY

[Signature]

TITLE

DATE

3-31-86

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

RECEIVED
APR 1 - 1986
O.C.D.
HOBBS OFFICE