Form 9-331 (May 1963)

## UNITED STATES JF THE INTERIOR (Other instructions verse side) DEPARTMEN

SUBMIT IN TRIPLIC TE:

Form approved. Budget Bureau No. 42-R1424. U. LEASE DESIGNATION AND SERIAL NO.

GEOLOGICAL SURVEY

CUNDRY NOTICES AND REPORTS ON WELLS

NM 0315712 6. IF INDIAN, ALLOTTEE OR TRIBE NAME

JUNDAL MOTICES	THE REPORTS OF THEE
(Do not use this form for proposals to Use "APPLICATION	drill or to deepen or plug back to a different reservoir. FOR PERMIT—" for such proposals.)

(Do not use this form for pro Use "APPL	carion for to deepen or plug back to a different reservoir.	
1.		7. UNIT AGREEMENT NAME
OIL GAS OTHER		Maljamar (Grayburg)
2. NAME OF OPERATOR		8. FARM OR LEASE NAME
Chevron Oil Company	6.	Maljamar Unit
B. ADDRESS OF OPERATOR		9. WELL NO.
P. O. Box 1660, Mid	land, Texas 79701	24
4. LOCATION OF WELL (Report location See also space 17 below.)	clearly and in accordance with any State requirements.*	10. FIELD AND POOL, OR WILDCAT
At surface		Maljamar (Grayburg-San And)
		11. SEC., T., R., M., OR BLE. AND SURVEY OR AREA
Unit M, 990' FSL, 3	30' FWL, Sec. 4, T-17-S, R-32-E, NMPM	•
		Sec. 4, T-17-S,R-32-E,NMPM
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.)	12. COUNTY OR PARISH 13. STATE
	DF 4092	Lea New Mexico

16.

## Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:			
TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE		PULL OR ALTER CASING MULTIPLE COMPLETE ABANDON*		WATER SHUT-OFF FRACTURE TREATMENT SHOOTING OR ACIDIZING	REPAIRING WELL ALTERING CASING ABANDONMENT®
REPAIR WELL (Other)		CHANGE PLANS		(Other)  (Note: Report results of m Completion or Recompletion	ultiple completion on Well Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) •

Work to commence before third quarter 1976. Federal office will be notified prior to commencing actual plugging operations.

- Dig pit and cellar.
- Run in hole with tubing, open ended, to 3700°, displace hole with 9.5 ppg mud laden fluid. Spot 25 sxs cement. Pull tubing to 2400' and spot 30 sxs cement. Pull tubing to 1000° and spot 35 sxs cement. Pull out of hole with tubing.
- Perforate 5½" casing at 343'. Pump sufficient cement to circulate to surface via annulus leaving 5½" casing full.
- Cut off casing 2-3' below ground level. Set 4' marker. Back fill pits and Clean up location as per Federal or State requirements.

18. I hereby certify that the foregoing is true and correct				
SIGNED Literard J. W. Leonard	TITLE _	Drilling Supervisor	DATE	3-1-76
(This space for Federal or State office use)	TITLE _	APPRO	NDED	de
CONDITIONS OF APPROVAL, IF ANY:		JUL 26	1976 B	
*See	Instruct	ions on Reverse Side ARTHUR F	R. BROWEER	

U. S. Geological Survey P. O. Box 1157 Hobbs, New Mexico

HOBBS DISTRICT

Operator:

Chevron Oil Company

Well:

No. 24 Maljamar Grayburg Unit

Lease No.

New Mexico 0315712

## CONDITIONS OF APPROVAL

- Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal Leases".
- 2. The Hobbs office (telephone (505) 393-3612) is to be notified in sufficient time for a representative to witness all plugging operations.
- 3. Blowout prevention equipment is required.
- 4. In addition to normal filling of pits and cleanup of location, additional surface restoration work <u>may</u> be required, i.e., ripping of pad and/or access road, reseeding, etc. After plugging the well and before making final clean-up, you should contact this office unless you have already been advised as to what additional surface restoration work is required.
- 5. Bottom of second plug (step 2) should be at 2600 instead of at 2400 feet.
- 6. If  $5\frac{1}{2}$ " casing is not pulled from below 1000 feet, perforate  $5\frac{1}{2}$ " casing at 1000 feet and squeeze with 100 sacks of cement, leaving 200-foot cement plug inside casing in interval 800 to 1000 feet.