

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
723

<p align="center"><b>SUNDRY NOTICES AND REPORTS ON WELLS</b></p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>		
1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Injection Well	7. Unit Agreement Name	
2. Name of Operator Ryder Scott Management Company	8. Farm or Lease Name Trimble A	
3. Address of Operator 922 - 8th Street, Wichita Falls, Texas 76301	9. Well No. 1	
4. Location of Well UNIT LETTER <u>B</u> , <u>1980</u> FEET FROM THE <u>East</u> LINE AND <u>660</u> FEET FROM THE <u>North</u> LINE, SECTION <u>11</u> TOWNSHIP <u>17</u> RANGE <u>32</u> NMPM.	10. Field and Pool, or Wildcat Maljamar	
15. Elevation (Show whether DF, RT, GR, etc.) 4165 GL	12. County Lea	

<p>16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data</p>			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Work to start on approval (approximately 3-18-68)

We will pull all retrievable tubing, install cast iron bridge plug above top perforations, fill casing and hole with mud-laden fluid, pull casing and install 10 sack cement plug in surface pipe. Erect marker & clean up surface.

1. Cap bridge plug w cement
2. 25 SXS @ casing stub
3. 25 SXS @ top of salt, if exposed
4. 25 SXS across surface casing shoe
5. 10 SXS @ sur face

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Madison TITLE Asst. Prod. Supt. DATE March 11, 1968

APPROVED BY Joe Ramsey TITLE Asst. Prod. Supt. DATE March 11, 1968

CONDITIONS OF APPROVAL, IF ANY: