

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name	
Cockburn Trimble	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Maljamar	
15. Elevation (Show whether DF, RT, GR, etc.)	
no record	
12. County	
Lea	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	
2. Name of Operator	
Ryder Scott Management Company	
3. Address of Operator	
922 - 8th Street, Wichita Falls, Texas 76301	
4. Location of Well	
UNIT LETTER <u>A</u> , <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM	
THE <u>East</u> LINE, SECTION <u>11</u> TOWNSHIP <u>17</u> RANGE <u>32</u> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	
no record	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Work to start on approval (approximately 3-18-68)

We will pull all retrievable tubing and rods, install cast iron bridge plug above top perforations, fill casing and hole with mud-laden fluid, pull casing and install 10 sack cement plug in surface pipe. Erect marker and clean up surface.

1. Cap bridge plug w cement
2. 25 sacks @ casing stub
3. 25 sacks @ top of salt, if exposed
4. 25 sacks across surface casing shoe
5. 25 sacks @ surface

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Mac Howard TITLE Ass't. Prod. Supt. DATE March 11, 1968

APPROVED BY Joe Ramsey TITLE Asst. Sec. DATE March 11, 1968

CONDITIONS OF APPROVAL, IF ANY