

# MACK ENERGY CORPORATION

MILLER BX 1  
SEC14 T17S R32E 660FSL 660FEL

- 1-20-88 Ran in hole acidize perms 3735-3910 with 1000 gals 15% ne acid  
NO SHOW
- 1-21-88 Acidize perms 3349-3460 with 1000 gals 15% ne acid NO SHOW
- 1-22-88 Acidize perms 2670-41 with 500 gals 15% ne acid
- 1-23-88 Swabing 6% oil
- 1-24-88 Swabing 6% oil
- 1-25-88 Swabing 6% oil
- 1-26-88 Fraced perms 2670-41 with 20000 gals gel
- 1-27-88 Pulled packer ran in hole with tbg and overshot circ sand  
PUT BACK ON PRODUCTION
- 9-22-88 Rods parted. Fished rods and layed down rods. Layed down tbg  
and T.A. well.

## 4-4-95 PROPOSE TO PLUG AND ABANDON AS FOLLOWS:

- 1 Circ hole w/mud laden fluid
- 2 ~~Set CIBP @ 4000' & spot 2sx plug on top plug~~
- 3 ~~Tag plug at 3950'~~
- 4 Spot 25sx plug 50' below base salt (2107')
- 5 Perf csg 50' below top salt (1193')
- 6 Squeeze perms w/25sx plug.
- 7 Tag plug @ 1093'
- 8 Perf csg 50' below 8 5/8" shoe.
- 9 Attempt to circ hole w/cmt from 200'.
- 10 Install dry hole marker and clean location.
- 11 We will need a workover pit on this location.

*Handwritten notes:*  
2600' w 25sx cmt  
@ 2590'  
#2 Spot Cmt Plug from ABTD to 2600'  
#3 Tag Plug @ 2600'