

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE
(Other instructions on
reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.
LC 029509(6)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ **WATER INJECTION WELL**

2. NAME OF OPERATOR
CONTINENTAL OIL COMPANY

3. ADDRESS OF OPERATOR
Box 460, HOBBS, N.M. 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

1980' FNL & 1980' FWL OF SEC. 22

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

MCA UNIT

9. WELL NO.
39

10. FIELD AND POOL, OR WILDCAT
MALJ. G-SA REPRESS.

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

SEC. 22, T-17S, R-32E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3995' DF

12. COUNTY OR PARISH

LEA

13. STATE

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☒

MULTIPLE COMPLETE ☐

ABANDON* ☐

CHANGE PLANS ☒

INSTALL LINER

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

In order to improve injection efficiency, it is proposed to install a liner by the following procedure: Set OH Bridge Plug @ ± 3870'. Place 5' to 10' sand & gravel on top w/ add'l 5' CALSEAL on top of sand. Run 300' 4 1/2" 9.5# K-55 csq. liner to set from 3670' to 3370'. Cement w/ 55 sks. Class "C" cmt. Set pack-off & apply squeeze w/ last 15 sks. Pressure test to 1500# & resqueeze if necessary w/ 50 sks Class "C". Drill out & clean out to TD. Run cmt. lined inj. tubing w/ 4 1/2" csq. pkr. to set @ ± 3600'. Place back on injection.

18. I hereby certify that the foregoing is true and correct

SIGNED

[Signature]

TITLE

SR. ANALYST

DATE

10-16-75

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED

DATE

OCT 20 1975

ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side

USGS-5. MCA-4. File