

MCA Unit #34

Surface casing: 8-5/8" 24# @ 1,050' cmt'd w/ 50 sx
Production csg: 7" 23# csg @ 3,650' cmt'd w/ 200 sx, sqz'd @ 900'
Liner csg: 4½" liner 4,174 – 3,489', cmt'd w/ 460 sx cmt
Openhole/perfs: 3,890 – 4,109'; TA'd w/ blanking plug in Otis Interlock packer @ 3,795' set 4/4/91

1. MIRU plugging equipment. NU BOP
2. RIH w/ tubing to PBTD @ 3,795'. Circulate hole w/ plugging mud and pump 25 sx C cmt on packer.
3. Perforate 7" casing @ 1,100' (top of salt & surface casing shoe).
4. Squeeze 75 sx C cmt under packer 1,100 – 1,000'.
5. WOC and tag cement no deeper than 1,000'.
6. Perforate 7" casing @ 60'.
7. Squeeze estimated 20 sx C cmt 60' to surface.
8. Cut off wellhead and install dryhole marker. Cut off anchors & close working pit.