

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 059152 (b)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Johns "B" DE

9. WELL NO.

7

10. FIELD AND POOL, OR WILDCAT

Maljamar Grbg SA

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

24-17S-32E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4106' RT

12. COUNTY OR PARISH

Lea

13. STATE

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☐
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

Plug & Abandon

☒

WATER SHUT-OFF

☐
☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐
☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well was last produced 3/23/78 after declining in production to less than 1 BOPD. No other zones of interest remain and the waterflood project is in the latter stages of depletion beyond economic limits. Propose to plug & abandon in the following manner: (TOC behind 5-1/2" csg @ 2780')

1. Rig up, kill well, install BOP.
2. RIH w/bit & scraper to 3975'.
3. RIH w/5-1/2" cmt retr, set retr @ 3950'. Squeeze cmt perfs below retr w/75 sx C1 C cont'g 4% gel. Spot heavy gelled mud between all plugs.
4. Perf 4 JS thru 5-1/2" csg opposite top of salt @ 1265'.
5. RIH w/cmt retr, set retr @ 1210'. Squeeze cmt thru retr w/20 sx C1 C cont'g 4% gel, 6# salt/sk.
6. Perforate 4 JS @ 200', swage top of 5-1/2" csg and displace 100 sx C1 C cmt cont'g 4% gel, 6# salt/sk, 2% CaCl. Circ cmt to surface. Spot 10 sx cmt @ surface.
7. Install regulation dry hole marker. Clean & level location.

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

RECEIVED

JUL 27 1978

U. S. GEOLOGICAL SURVEY
HOBBS NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature]

TITLE Dist. Drlg. Supt.

DATE 7/25/78

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED
AS AMENDED

JUL 28 1978

A. A. L.

ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side