Form 9-331 (May 1963)

14. PE

1G.

## UNITED STATES DEPARTMENT OF THE INTERIOR (Other instructions on reverse side) SUBMIT IN TRIPLICATE\*

Form approved.
Budget Bureau No. 42-R1424.

GEOLOGICAL SURVEY	LC 058697 (b)
SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir Use "APPLICATION FOR PERMIT—" for such proposals.)	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
L X GAS GTHER	7. UNIT AGREEMENT NAME
	MOA
ME OF OPERATOR	8. FARM OR LEASE NAME
Continental Sil Company	MCA Unit
DRESS OF OPERATOR	9. WELL NO.
P. O. Box 460. Hobbs. New Mexico	127
CATION OF WELL (Report location clearly and in accordance with any State requirements.* e also space 17 below.)	Maljamar Repress.
660' FNL & 660' FWD, Section 23, T-178, R-32E, Lea County, New Mexico.	(CSA) POOT 11. SEC, T., R., M., OR BLK. AND SURVEY OR AREA
RMIT NO.   15. ELEVATIONS (Show whether DF. ET. OR. etc.)	Sec. 25, T-17S, R-32E

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING
WATER SHUT-OFF

FRACTURE TREAT
MULTIPLE COMPLETE
SHOOT OR ACIDIZE

SHOOTING OR ACIDIZING

ABANDON\*

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

SUBSEQUENT REPORT OF:

REPAIRING WELL
ALTERING CASING
SHOOTING OR ACIDIZING

ABANDONMENT\*

REPAIR WELL CHANGE PLANS

(Other) Convert to Water Inject. X

(Other) Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Approval of the New Mexico Oil Conservation Commission to convert this well to water injection for the MCA Unit Waterflood Expansion was obtained under Administrative Order WFX No. 267, dated August 27, 1967. Therefore, it is proposed to convert the well using the following procedure:

- 1. Check for fill and clear out if necessary.
- 2. Run Gamma Ray-Neutron log.
- 3. Run cement-lined tubing w/packer set at approximately 3,740'.
- 4. Place well on injection.

	TITLE .	Supervising Engineer	DATE 9-11-67
(This space for Federal or State office use)  APPROVED BY	TITLE		
CONDITIONS OF APPROVAL, IF ANY:  USGS-5 PARTNERS-15 PILE	TITUM.	1967	DATE