

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-01229
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	LG-474
7. Lease Name or Unit Agreement Name	State C
8. Well No.	2
9. Pool name or Wildcat	Saunders Permo Upper Penn

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator Westbrook Oil Corporation	
3. Address of Operator PO Box 2264 - Hobbs NM 88240	
4. Well Location Unit Letter C : 660 Feet From The North Line and 1980 Feet From The West Line Section 4 Township 15S Range 33E NMMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Work to start approximately August 5, 1996

- 1 - Set CIBP @ 9778' w/35' cement on top.
- 2 - Displace hole with mud laden brine.
- 3 - Pump a 100' cement plug 6500' to 6400'
- 4 - Cut 5-1/2" casing 4475' and pull.
- 5 - Run 100' cement plug, 50' in stub and 50' out.
- 6 - Pump 100' cement plug 3000' to 2900'.
- 7 - Pump 100' cement plug 1600' to 1500'
- 8 - Cut & pull 7-5/8" casing @ 700'. Cement plug from 750' to 500'
- 9 - Pump 10 sk plug at surface and set well I.D. marker 14" pipe 5' above surface
- 10 - Clean location and cut off anchors.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE V. H. Westbrook TITLE Agent DATE 7/30/96  
TYPE OR PRINT NAME V. H. Westbrook TELEPHONE NO. 393-9714

(This space for State Use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

JUL 29 1996