

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-5711

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Imperial-American Management Co.	8. Farm or Lease Name Saunders State
3. Address of Operator 507 Midland Savings Bldg., Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER P 660 FEET FROM THE South LINE AND 660 FEET FROM THE East LINE, SECTION 9 TOWNSHIP 15-S RANGE 33-E NMPM.	10. Field and Pool, or Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 4188 GR	12. County Lea

16.

### Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐  
OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well apparently has not been plugged and abandoned as previously reported. We propose to open well and check for plugs as previously reported, if no plugs exist, we propose to P&A as follows:

1. Load hole w/9.5# mud.
2. Set 30 sx cement plug 5300-5550' - casing split from 5520-5549'. Squeezed off w/150 sx - got outside of csg while drilling out. Cannot get deeper than this to set plugs.
3. Shoot off 5 1/2" csg at free point, est. 3000', and pull same.
4. Set 30 sx cement plug at base of salt section, 2500-2600' in 8-5/8" csg.
5. Set 30 sx cement plug at top of salt section, 1500-1600' in 8-5/8" csg.
6. Set 10 sx cement plug at surface 0-30'.
7. Remove wellhead, weld plate on csg., set surface marker, clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>David K. Ramsey</u>	TITLE <u>Division Manager</u>	DATE <u>3-22-71</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>SUPERVISOR DISTRICT</u>	DATE <u>MAR 26 1971</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

MAR 25 1971

OIL CONSERVATION COMM.  
HOBBS, N. M.