

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-2148
7. Lease Name or Unit Agreement Name State 18B B
8. Well No. #2
9. Pool name or Wildcat Maljamar Grayburg San Andres

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Injection	
2. Name of Operator Murphy H. Baxter	
3. Address of Operator P. O. Box 2040, Midland, TX 79702	
4. Well Location Unit Letter <u>H</u> : <u>1980</u> Feet From The <u>North</u> Line and <u>660</u> Feet From The <u>East</u> Line Section <u>18</u> Township <u>17 S</u> Range <u>33 E</u> NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Squeeze perfs @ 4231' - 4534' w/ 100 sks. of cement. Shut well in overnight.
- Pressure tested plug to 1500#'s. -okay.
- Cut tubing @ 3415'.
- Spot 25 sks. of cement @ 3415'.
- Circulate hole with mud.
- Perforated @ 300'.
- Pumped 84 sks. of cement. Circulated cement to surface via 5 1/2 x 8 5/8" annulus, leaving 5 1/2 full of cement.
- Cut off wellhead. Install dry hole marker.
- Clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE <u>G. A. Baber</u>	TITLE <u>President</u>	DATE <u>4-17-89</u>
TYPE OR PRINT NAME <u>G. A. Baber</u>		TELEPHONE NO. <u>505-393-5516</u>

(This space for State Use)

APPROVED BY [Signature] TITLE OIL & GAS INSPECTOR DATE AUG 29 1989

CONDITIONS OF APPROVAL, IF ANY:

Plotted 4/19/89 D

RECEIVED

APR 19 1989

OCD
HOBBS OFFICE