

New Mexico Oil Conservation Commission
Form C-103 (cont.)

14. Set CIBP at 11,900' and 10,400'. Dump 2 sacks cement on each plug.
15. Acidize existing Wolfcamp perforations 10,304'-10,371' w/1000 gal. 15% HCL acid and swab test.
16. Run in hole w/rods and pump.
17. Test Wolfcamp zone. Initial potential 49 BO, 149 BW in 24 hours. Gas rate 40.2 MCF/day.