

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator <b>TEXAS PACIFIC OIL CO., INC.</b>		8. Farm or Lease Name <b>STATE "J"</b>
3. Address of Operator <b>P. O. Box 1069 - Hobbs, New Mexico 88240</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>X</b> , <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>10</b> TOWNSHIP <b>16-S</b> RANGE <b>35-E</b> NMPM.		10. Field and Pool, or Wildcat <b>Townsend Wolfcamp</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4004' GR</b>		12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRU. Set Packer @ 10,250'
2. Squeeze perfs 10,500 - 538' w/200 sks. Pull packer. WOC 12 hrs.
3. Drill out cement 10,500 - 538'; 10,601 - 650'. Clean out open hole 10,650 - 12,000'.
4. Log 10,650 to 12,000'. If logs indicate sufficient porosity:
5. Run 4" hydril 10.46# N-80 liner 10,450 - 12,000'.  
Cement w/300 sks. WOC 18 hrs.
6. Test and place on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed By  
Claude Aubert, Jr.

SIGNED \_\_\_\_\_ TITLE **Area Superintendent** DATE **6-8-73**

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: