

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION
**Orig&2ec: NMCCC-Hobbs; cc-State
 Land Office; cc: RFB, File,
 R.L. McClain**

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-10646-12

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
 USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Sinclair Oil & Gas Company	8. Farm or Lease Name State-Grambling WN
3. Address of Operator P.O. Box 1920	9. Well No. 1
4. Location of Well UNIT LETTER A 660' FEET FROM THE North LINE AND 660' FEET FROM THE East LINE, SECTION 34 TOWNSHIP 16S RANGE 35E NMPM.	10. Field and Pool, or Wildcat Shoe Bar Penn
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**Depth: 12360PB 13-3/8" csg set @ 335 & cement circulated to surface
 9-5/8" csg set @ 4984 & cement circulated to surface
 7" csg set at total depth & cemented back to 8795
 7" OD csg perforated 12310-12350**

PROPOSE TO PLUG AND ABANDON WELL AS FOLLOWS:

Fill hole w/heavy mud and set CI Bridge Plug at 12290 w/2 sks cement on top of bridge plug. Cut & RYM pull 7" OD Csg from approximately 8500'. Set 25 sk cement plug in top of 7" csg stub. Set 25 sk cement plug at 7680, 6370 and in bottom of 9-5/8" csg at 4984. Set 10 sk cement plug in top of 13-3/8" csg & install regulation marked. Clean and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *R.L. McClain* TITLE **Superintendent** DATE **4-20-65**

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: