

NO. OF COPIES RECEIVED	
DISTRIBUTION	
DATE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Sun Oil Company		8. Farm or Lease Name J. D. Graham
3. Address of Operator P. O. Box 1861, Midland, Texas 79701		9. Well No. 1
4. Location of Well UNIT LETTER 0 2310 FEET FROM THE East LINE AND 330 FEET FROM THE South LINE, SECTION 9 TOWNSHIP 15-S RANGE 36-E NMPM.		10. Field and Pool, or Wildcat Caud111 Permo Penn
15. Elevation (show whether DF, RT, GR, etc.) 3923 DF		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Set CIBP @ 10180, spot 15 sx cement plug on top CIBP.
- 2) Circulate hole w/9.5# mud.
- 3) Shoot and pull 5-1/2" casing. Spot 40 sx cement plug 50' in and out of casing stub. Estimated recovery 6000'.
- 4) If 5-1/2 casing recovered below 6124, spot 60 sx cement plug across the top of the Glorieta at 6124'.
- 5) Spot 50 sx cement plug 50' in and out of 8-5/8" casing seat at 4749'.
- 6) Shoot and pull 8-5/8" casing from 500'.
- 7) Spot 125 sx cement plug 550' to 325'.
- 8) Spot 20 sx cement plug at surface, weld on cap, install permanent marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Charles Gray TITLE Proration Analyst DATE 1-24-75

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: None