

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
08700

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator CITIES SERVICE OIL COMPANY	8. Farm or Lease Name State BM
3. Address of Operator P.O. Box 69, Hobbs, New Mexico 88240	9. Well No. 2
4. Location of Well UNIT LETTER <u>L</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>16</u> TOWNSHIP <u>15S</u> RANGE <u>36E</u> NMPM.	10. Field and Pool, or Wildcat Caudill Permo Penn
15. Elevation (Show whether DF, RT, GR, etc.) 3920 DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/>

Shut In

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 13,596, Caudill Permo Penn. We propose to plug and abandon this well in the following manner:

1. Load hole with mud laden fluid
2. Set bridge plug at 10,600'
3. Shoot off and recover 5450' of 5 1/2" casing
4. Displace 30 sack cement plug 1/2 in and 1/2 out of 5 1/2" casing stub
5. Displace 30 sack cement plug 1/2 in and 1/2 out of 8 5/8" casing shoe @ 4750'
6. Dump 10 sack cement plug in top of 8 5/8" casing from ground level to 30'
7. Reclaim well head and install 4" dry hole marker
8. Cover and level pit. Clear location of all material and debris.

100' plugs

35' cement on BP

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Kenneth W. Stover TITLE Production Engineer DATE June 19, 1972

APPROVED BY Joe D. Ramey TITLE Dist. I, Supv. DATE JUN 22 1972

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JUN 11 1972

Mississippi
State Highway
Department

OIL COMPANY (STREET) COMMAL.
HOUSTON, TEXAS