

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator Cities Service Company		8. Farm or Lease Name Crockett	
3. Address of Operator P.O. Box 1919 Midland, TX 79702		9. Well No. 1	
4. Location of Well UNIT LETTER <u>D</u> <u>940</u> FEET FROM THE <u>West</u> LINE AND <u>940</u> FEET FROM THE <u>North</u> LINE, SECTION <u>21</u> TOWNSHIP <u>15S</u> RANGE <u>36E</u> NMPM.		10. Field and Pool, or Wildcat Caudill Permo Penn	
15. Elevation (Show whether DF, RT, GR, etc.) 3914 DF		12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 13,593', PBTD 10,700'. We propose to plug & abandon this well as follows:

1. MIRU pulling unit & pull rods. Release packer & load hole with mud laden fluid. POOH with tubing & packer.
2. Dump 4 sx cmt on top of CIBP @ 10,700' with dump bailer.
3. Set CIBP on wireline at 10,450'. Dump 4 sx cmt on CIBP with dump bailer.
4. Move off pulling unit A MIRU csg puller.
5. Determine free point & shoot off & recover 5½" csg.
6. RIH with open ended tbg & spot the following plugs:
 - a) 150' cmt plug ½ in and ½ out of 5½" csg stub.
 - b) 150' cmt plug ½ in and ½ out of 8-5/8" csg shoe.
 - c) 10 sx cmt surface plug in top of the 8-5/8" csg.
7. Reclaim all equipment & material & install 4" dry hole marker.
8. Clear location of all material & debris.

100' plug Top Wolf.
100' plug Top Abo
100' plug Top Glavie
100' plug Top & Bottom Salt } if not behind file

Engr. 12-2-79

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>[Signature]</u>	TITLE <u>Region Operations Mgr.</u>	DATE <u>6/4/79</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>Geologist</u>	DATE <u>JUN 7 1979</u>
CONDITIONS OF APPROVAL, IF ANY:		

Note above