

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-529
7. Unit Agreement Name
8. Farm or Lease Name NEW MEXICO AT STATE
9. Well No. 1
10. Field and Pool, or Wildcat DEAN PERMO PENN
12. County LEA

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator EXXON CORPORATION
3. Address of Operator P.O. Box 1600, MIDLAND, TEXAS 79701
4. Location of Well UNIT LETTER 0 660 FEET FROM THE SOUTH LINE AND 1980 FEET FROM THE EAST LINE, SECTION 26 TOWNSHIP 15-S RANGE 36-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3870 DF

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

PLUG AND ABANDON	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>
CASING TEST AND CEMENT JOB	<input type="checkbox"/>
OTHER	<input type="checkbox"/>
ALTERING CASING	<input type="checkbox"/>
PLUG AND ABANDONMENT	<input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

PLUGGING PROCEDURE:

- UNSEAT THE FULLBORE CEMENTER AT 10,646' AND LOWER RETRIEVABLE BRIDGE PLUG TO 11,200'.
- CIRCULATE CSG. WITH MUD CONSISTING OF 25 SK. OF CEL TO 100 BBLs. BRINE.
- PULL TBC WITH PACKER AND B.P.
- SET A CI BP AT ABOUT 10,300' AND DUMP 25' (4 SK) CEMENT ON TOP
- ESTABLISH FREE POINT AND CUT 5 1/2" CSG AT ABOUT 3195'. PULL 5 1/2" CSG.
- ESTABLISH FREE POINT AND CUT 9 5/8" CSG AT ABOUT 780'. PULL 9 5/8" CSG.
- RUN TBC. OPEN ENDED TO 5 1/2" CSG. CUT AND REFILL HOLE WITH MUD.
- SPOTT 100' CLASS 2" CEMENT PLUGS WITH MUD AS FOLLOWS:
 - 35 SK. FROM 50' BELOW THE 5 1/2" CUT TO 1950' (ACROSS THE TOP OF RUSTLER)
 - 70 SK ACROSS THE 9 5/8" CUT.
 - 100 SK FROM 290' TO 390' ACROSS THE SURFACE CASING SHAPE.
 - 10 SK AT THE SURFACE
- CLEAN UP LOCATION AND SET WELL MARKER * Notify O.C.C. 24 hours
- NOTIFY N.M.O.C.C. REP. TO INSPECT LOCATION before setting bottom plug

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Unit Head	TITLE UNIT HEAD	DATE 5-17-73
APPROVED BY John W. Runyon	TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:		