

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION OFFICE O. C. C.

3-NMOCC
1-File

Dec 16 1 03 PM '66

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)</p>		<p>5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/></p> <p>5. State Oil & Gas Lease No.</p>
<p>1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/></p> <p>2. Name of Operator Tidewater Oil Company</p> <p>3. Address of Operator Box 249, Hobbs, New Mexico 88240</p> <p>4. Location of Well UNIT LETTER N 1980 FEET FROM THE West LINE AND 660 FEET FROM THE South LINE, SECTION 26 TOWNSHIP 15 S RANGE 36 E NMPM.</p>	<p>7. Unit Agreement Name</p> <p>8. Farm or Lease Name State AE</p> <p>9. Well No. 1</p> <p>10. Field and Pool, or Wildcat Dean Permo Penn</p>	
<p>15. Elevation (Show whether DF, RT, GR, etc.)</p>		<p>12. County Lea</p>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to plug and abandon this well as follows:

1. Lay 25 sk cement plug at 10,400'.
2. Lay 25 sk cement across top of 7" stub which will be at 5845' or above. This is above the Abo (8352'), Tubb (7625') and Glorieta (6503') formations.
3. Lay a 25 sk cement plug in and out bottom of 9-5/8", across top of 9-5/8" stub, in and out bottom of 13-3/8" and 10 sks at surface.
4. Install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed By

SIGNED **C. L. WADE**

TITLE **Area Supt.**

DATE **12-14-66**

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: