

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

HOBBS OFFICE O. C. JUN 6 10 20 AM '69

NEW MEXICO OIL CONSERVATION COMMISSION

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-605
7. Unit Agreement Name
8. Farm or Lease Name State AW
9. Well No. 1
10. Field and Pool, or Wildcat Dean Devonian
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Cities Service Oil Company
3. Address of Operator P. O. Box 69 - Hobbs, New Mexico 88240
4. Location of Well UNIT LETTER 0 660 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 35 TOWNSHIP 15S RANGE 36E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3850 GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug and abandon this well in the following manner.

1. Pull rods and tubing - Set BOP.
2. Set CIBP @ 10620' and dump one sack cement on top.
3. Cut 5½" casing @ 9195' and recover approximately 4500'.
4. Run tubing and fill hole w/heavy mud.
5. Set 30 sack plug ½ in and ½ out of 5½" casing.
6. Set 10 sack cement surface plug and set required marker.
7. Clean location of all equipment and debris, fill pits and level location.

25' to 10' in + 10' in
shale

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE **District Office Manager** DATE **June 6, 1969**

APPROVED BY [Signature] TITLE [Signature] DATE **JUN 11 1969**

CONDITIONS OF APPROVAL, IF ANY: