

OF COPIES RECEIVED	
DISTRIBUTION	
SALE A FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION
3-NMOCC
1-File

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-7845	
7. Unit Agreement Name	
8. Farm or Lease Name STATE "M"	
9. Well No. 3	
10. Field and Pool, or Wildcat LOVINGTON ABO	
12. County LEA	

SUNDY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator GETTY OIL COMPANY
3. Address of Operator P.O. BOX 249, HOBBS, NEW MEXICO 88240
4. Location of Well UNIT LETTER J, 1650 FEET FROM THE SOUTH LINE AND 1650 FEET FROM THE EAST LINE, SECTION 36 TOWNSHIP 16S RANGE 36E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3838 RT

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to P & A the State "M" Well No. 3 as follows:

1. Load hole with mud; pull tubing; and set CIBP at 3050'; and spot 35' of cement on top of BP.
2. Pick up tubing to 4660' and spot 100' of cement from 4660' to 4560'.
3. Pick up tubing to 3211' and spot 100' cement plug from 3211 to 3111'.
4. Pick up tubing to 2100' and spot 100' cement from 2100' to 2000'.
5. Pull tubing out of hole; salvage well head equipment; and spot 10 sack cement plug at surface; and erect "DRY HOLE" Marker.
6. Level location; fill pits; and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C.L. Wade G. D. Wade TITLE AREA SUPERINTENDENT DATE SEPT. 10, 1974

APPROVED BY [Signature] Orig. Signed by Joe D. Ramey
CONDITIONS OF APPROVAL, IF ANY: Dist. I, Supv.

TITLE _____ DATE _____