

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Nov 28 11 00 AM '66

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-7845
7. Unit Agreement Name Lovington Paddock Unit
8. Farm or Lease Name ---
9. Well No. 33
10. Field and Pool, or Wildcat Lovington Paddock
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator Skelly Oil Company
3. Address of Operator P.O. Box 730, Hobbs, New Mexico
4. Location of Well UNIT LETTER I , 1650 FEET FROM THE South LINE AND 430 FEET FROM THE East LINE, SECTION 36 TOWNSHIP 14S RANGE 36E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3831' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
OTHER Deepen and convert well to water injection. <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

1. Move in and rig up Pulling Unit.
2. Pull rods and tubing.
3. Rig down and move out Pulling Unit.
4. Move in and rig up Workover Rig.
5. Run drill pipe with 6-1/4" bit and clean out hole to old total depth 6150'.
6. Drill new hole from 6150' to 6235'.
7. Run electric logs.
8. Spot 500 gallons regular acid on bottom.
9. Rig down and move out Workover rig.
10. Move in and rig up Pulling Unit.
11. Run plastic coated tubing and packer.
12. Install water injection equipment and inject water through 7" casing perforations 6040-6140' and open hole section 6150-6235' into the Paddock Formation.

This well will be a Water Injection Well for the Lovington Paddock Unit, which is operated by Skelly Oil Company.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED **(ORIGINAL SIGNED) H. E. Aab** TITLE **Dist. Superintendent** DATE **Nov. 25, 1966**

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: