

OIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> TA GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator ARCO Oil and Gas Company Division of Atlantic Richfield Company	8. Farm or Lease Name Lee Whitman "A"
3. Address of Operator Box 1710, Hobbs, New Mexico 88240	9. Well No. 4
4. Location of Well UNIT LETTER H 660 FEET FROM THE South LINE AND 825 FEET FROM THE East LINE, SECTION 26 TOWNSHIP 14S RANGE 37E NMPM.	10. Field and Pool, or WHdcat Denton Devonian
15. Elevation (Show whether DF, RT, GR, etc.) 3821' DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input checked="" type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

- RU, install BOP, rel pkr & POH w/comp1 assy.
- Set cmt retr @ 12,200', cmt squeeze Dev perfs 12,244-12,645' w/C1 H Neat cmt. Dump 50' cmt on top of retr.
- Spot 9.5# plus gelled mud 12,150-9500' below hole in 7" csg.
- Run pkr & isolate hole in 7" csg, establish injection rate thru hole @ approx 9350'.
- Set cmt retr above hole & cmt squeeze w/C1 H Neat cmt, dump 50' cmt on top of retr.
- Circ hole w/9.5# plus gelled mud to surf.
- ND BOP, RIH w/1 jt EUE tbg, install tbg head & 2" gate valve, close in. Temporarily abandon, hold for future use.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Roland E. Ballinger TITLE Drlg. Engr. DATE 8/4/83

ORIGINAL SIGNED BY JERRY SEXTON

APPROVED BY DISTRICT 1 SUPERVISOR TITLE  DATE AUG 5 1983

CONDITIONS OF APPROVAL, IF ANY: