

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 87240
District II
811 South First, Artesia, NM 87210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-025-05144
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>		5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
2. Name of Operator Stephens & Johnson Operating Co.		6. State Oil & Gas Lease No.
3. Address of Operator P O Box 2249, Wichita Falls, TX 76307-2249		7. Lease Name or Unit Agreement Name: T. D. Pope
4. Well Location Unit Letter N : 660 feet from the South line and 1980 feet from the West line Section 26 (SE SW) Township 14S Range 37E NMPM County Lea		8. Well No. 9
10. Elevation (Show whether DR, RKB, RT, GR, etc.)		9. Pool name or Wildcat Denton Devonian

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐
OTHER: ☐

SUBSEQUENT REPORT OF:
REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Will plug and abandon this well. There is junk tubing (2 3/8" & 1") in the hole from about 7800' to TD.

See attached procedure.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE _____ TITLE Manager of Operations DATE 7-1-02

Type or print name Peyton S. Carnes, Jr. Telephone No. 940-723-2166
(This space for State use) OC FIELD REPRESENTATIVE II/STAFF MANAGER

APPROVED BY _____ TITLE _____ DATE 3-0-2002

Conditions of approval, if any:

ORIGINAL SIGNED BY
GARY W. WINK
OC FIELD REPRESENTATIVE II/STAFF MANAGER

T. D. POPE WELL NO. 9

Plugging Procedure:

- 1) Run 5 1/2" cement retainer on tubing and set at 7800'±.
- 2) Pump 250 sacks of cement below retainer, sting out of retainer and spot 25 sacks of cement on top of retainer.
- 3) Tag plug and load hole with 9.5# mud laden salt water.
- 4) Spot 50 sack plug 50' inside of 5 1/2" liner (4642') to 4440' inside of 8 5/8" casing. Tag plug.
- 5) Spot 30 sack plug at 3150' in 8 5/8" casing.
- 6) Spot 30 sack plug at 2200' in 8 5/8" casing.
- 7) Spot 125 sack plug 50' below surface casing to surface in 8 5/8" casing.
- 8) Cut off casing 3' below ground and install permanent marker.