

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPlicate
(Other instruction
reverse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

5. LEASE DESIGNATION AND SERIAL NO.

LC 065254

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Jones Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Denton Devonian

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 35, T14S, R37E

12. COUNTY OR PARISH

Lea

13. STATE

N.M.

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Atlantic Richfield Company

3. ADDRESS OF OPERATOR

P. O. Box 1978, Roswell, New Mexico 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

660' FSL & 660' FWL (Unit letter M)

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3820' DF

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*

Production from Devonian perfs 12442-12610' declined to 6 BOPD + 98% water in May, 1972. The well is no longer economical to produce and no remedial prospects exist. We propose to P & A as follows:

1. Set CIBP in 7" casing at 12375' and cap w/35' of cement.
2. Load well w/gel mud and shoot off and recover 7" casing from free point (top of cement @ 7370').
3. Place 30 sk (100') cement plug @ 7" stub.
4. Place 35 sk (100') cement plug @ 9-5/8" shoe @ 4678'.
5. Place 10 sk cement plug in top of well.

13-3/8" and 9-5/8" casing strings were both cemented to surface and will remain intact. Dry hole marker will be erected and surface cleaned and levelled for inspection.

AMENDMENT: 1. Place additional 100' plug inside 9-5/8" csg. at 2100-2200 feet.
2. If 7" casing is pulled from below 6300 feet place 100' plug at 6200-6300 feet (Glorieta).

18. I hereby certify that the foregoing is true and correct

SIGNED

D. D. Satchers

TITLE

Dist. Drlg. Supervisor

DATE

10/31/72

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side