

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name B.C. Dickinson "D"
9. Well No. 1
10. Field and Pool, or Wildcat Denton-Devonian
12. County Lea

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Atlantic Richfield Company
3. Address of Operator P.O. Box 1978, Roswell, New Mexico 88201
4. Location of Well UNIT LETTER <u>N</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>35</u> TOWNSHIP <u>14-S</u> RANGE <u>37-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3834' DF

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well last produced in December, 1963 when the Devonian formation was depleted. This well is not needed in the North Denton Wolfcamp unit. No recompletion possibilities exist and we propose to P & A as follows:

1. Load hole w/9#/gal gel mud containing 25 sx gel/100 BW.
2. Set 5½" CIBP at 12225' and cap w/2 sx cement.
3. Shoot off and recover 5½" csg from free point (TOC @ 6802').
4. Set 30 sx (130' long) cement plug in & out of 5½" stub.
5. Set 40 sx (115') cement plug across 8-5/8" shoe @ 4665'.
6. Set 10 sx in top of well & erect dry hole marker.

13-3/8" & 8-5/8" casing strings will remain intact. Location will be cleared & levelled.

*Note CIBP must be capped with minimum of 35' plug*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>O.D. Britches</u>	TITLE <u>Dist. Drlg. Supervisor</u>	DATE <u>3/24/72</u>
Orig. Signed by John Runyan Geologist		
APPROVED BY _____	TITLE _____	DATE <u>MAR 29 1972</u>
CONDITIONS OF APPROVAL, IF ANY:		